

Durastripe Installation Instructions

T: +44 (0) 1707 800060
F: +44 (0) 1707 657282
E: info@versatileflooring.co.uk
www.versatileflooring.co.uk



Applications:

- Aisle markings
- To fix Ergo mats to sub-floor
- De-marking of floor areas

Advantages:

- Exceptional durability
- Quick and easy to install
- 8 Colours 1 hazard colour (black and yellow)
- Versatility

Product range:

- Standard Tape 5cm, 7.5 cm and 10 cm
- Lean Hazard Tape
- Shapes (Letters, numbers, footprints, Arrows, Circles)

Installation Guide lines for Concrete floors:

Concrete sub-floors are generally not in the best condition and have surface dust which will affect the tapes adhesion. All concrete sub-floors should be primed using Uzin PE360 Primer (Penetrates in to the sub-floor, Binds surface dust)

The subfloor should be swept prior to priming. After sweeping you can apply the primer with a 4" roller. This is ideal for all sizes of tape and shapes to be installed. The idea of the primer is to bind all surface dust and also for the tapes acrylic adhesive to bond fully with the floor. Best methods for installation are to firstly measure the area for the tape is to be applied. The lines can be drawn out with either a chalk line or 2/3mtr metal straight edge. Once the lines have been pencilled out you can then prime along them using the 4" roller. This will normally take around 15 minutes to dry. (Make sure the primer is totally dry before applying tape). Once this is done you can then roll the tape over the line ensuring the edge is parallel to the pencil/chalk line. Starting at one end peel back the tape and work down the line, (be very cautious not to stretch the tape when sticking as this will shrink when the tape settles. This will cause gaps in the tape at the joints.) Ensure that you rub over the tape with a dry cloth to ensure full adhesion to sub-floor and all air bubbles have been rubbed out. In extreme cases the concrete floor may be oil contaminated or have surface grease. Clean the area with UZIN RG194 degreaser prior to priming.

Epoxy/resin floors:-

These floors are generally smooth and have a good surface. Ensure the surface is clean and dust free. The use of primer is not needed unless the floor is in very bad condition. Follow installation instructions above.

Installation of shapes: Follow guide lines above for Sub-floor type. Be very cautious with shapes and ensure they get a full adhesion to the floor

Key Benefits

- Extremely Hard wearing, other tapes rip and tear and need replacing on a regular basis, save time, effort and money with Durastripe.
- Flexible layout - Painted systems are a permanent fixture and cannot be moved. Durastripe can be changed to suit layout requirements
- Easy to clean surface
- Easy to repair should the tape get damaged or vandalised
- Will outlast all conventional line marking tapes

Specific caution should be taken in areas that are as follows or liable to misuse: Damaged sub-floors / Damp / oil contaminated floors / Pallets / stillages beings dragged or pushed across floor / Very low temperatures



The Versatile Flooring Company

1 Devonshire Business Centre
Cranborne Industrial Estate
Potters Bar Hertfordshire EN6 3JR
T: + 44 (0) 01707 800060
F + 44 (0) 1707 657282
www.versatileflooring.co.uk
info@versatileflooring.co.uk

