



---

**Guidelines for gluing Ecotile to be read in conjunction with Uzin MSDS for MK92 S**

1. Prepare the substrate in accordance with the instructions on the accompanying Uzin data sheet.
2. For areas less than 50m<sup>2</sup> / with lots of cuts lay the tiles before moving to step 4.
3. For large areas lay out the first tiles until you are confident that they are square then move to step 4 and glue as you go along.
4. Mix resin and hardener together mechanically with a mixing drill and paddle until no streaks can be seen.
5. Pour approximately 10% of the mixture on to the floor and spread with a 2ml V notch trowel.
6. Lay the tiles and connect the lugs by tapping with a rubber mallet.
7. If any excess glue seeps up through the joints clean off immediately with industrial handwipes.

NB : The pot life is 30 minutes once mixed.