



waterhog
High performance matting

Designed to remove water and dirt from fork lift trucks as they enter your building, therefore significantly improving safety and reducing the need for cleaning.

Placing a forklift mat at the entrance of the warehouse will help remove up to 85% of the water from the fork lift truck tyres as well as trapping dirt, wood splinters, leaves etc. A quick, very simple and extremely cost effective solution.

Surface	
Type:	Solution Dyed Polypropylene Fibre
Pattern:	Circles
Weight:	814 gr/m ²
Colour:	Charcoal
Backing	
Backing Type:	100% SBR Rubber (20% Recycled Content)
Thickness:	1mm
Total Mat	
Tile Size:	120 x 172cm
Weight:	10.5kg
Height:	6.3mm
Testing Information	
Fire Resistance:	Passes Flammability Standard DOC-FF-1-70
Slip Resistance:	Certified Slip Resistant by The National Floor Safety Institute

Features:

- Recommended for all areas where forklifts and heavy traffic travel from outside into a building
- Exclusive rubber reinforced bi-level pattern effectively removes dirt and water from forklift wheels and stores dirt and moisture beneath wheel level for later cleaning
- Improve lift truck and worker safety by keeping floors clean and dry
- Crushproof reinforced rubber nubs withstand the weight of a loaded forklift - tested up to 6300kg
- Scalable modular mats can be laid and arranged to fit any shape or area size
- Quick and simple double sided tape installation requires very little downtime, so areas can remain open
- Individual tiles can be lifted and replaced if damaged or otherwise
- Low profile mat enables smooth transition of forklifts and minimises trip hazard for pedestrians
- Quick drying fabric and easy to clean with pressure washer, vacuum or commercial carpet cleaning equipment

Before:



After:



Additional Product Information	
Recommended Tape:	Jantex Impact Tape 50mm x 50m
Price per Matt:	£299.00 + VAT & Delivery
Price per Roll of Tape:	£30.00 + VAT

Waterhog™ Modular Forklift Mats - Installation Instructions

Waterhog Modular Forklift Mats are quick and simple to install when following the instructions below. Ensure you use the correct tape for the tiles and clean the area beforehand, removing any dust or grease that may affect the adhesive properties of the tape.

Time required: 10 minutes per tile

Equipment Required: Scissors or sharp knife to cut the tape & double sided tape.

Instructions:

1. Place the Waterhog Modular Forklift Mat face down with the rubber backing side up.
2. Tape along all 4 sides of the tiles as close to the edge as possible.
3. Inside the rectangle, create an X by placing tape, sticky side down (Blue side up) from one corner diagonally to the opposite corner.
4. Place mat in position, carefully fold one half of the mat back, exposing the tape.
5. Remove the backing tape and trim back to the folded area. Fold that half back into place and repeat on the other side.
6. To secure bond between tape and tile, apply pressure by walking around each side of the tile. At this time, installation of the tile is complete. Subsequent tiles may be placed immediately after the installed tile with the edges touching or a small gap left.

